



Tool Model: 3 SL

Pressure/Torque Conversion Chart

PRESSURE IN: PSI	ft-lbs	NM
1500	448	607
1600	475	644
1700	505	685
1800	535	725
1900	565	766
2000	595	807
2100	625	847
2200	655	888
2300	685	929
2400	715	969
2500	745	1010
2600	775	1051
2700	805	1091
2800	835	1132
2900	865	1173
3000	895	1213
3100	923	1251
3200	950	1288
3300	980	1329
3400	1010	1369
3500	1043	1413
3600	1075	1457
3700	1103	1495
3800	1130	1532
3900	1160	1573
4000	1190	1613
4100	1220	1654
4200	1250	1695
4300	1280	1735
4400	1310	1776
4500	1340	1817
4600	1370	1857
4700	1400	1898
4800	1430	1939
4900	1458	1976
5000	1485	2013
5100	1518	2057
5200	1550	2101
5300	1580	2142
5400	1610	2183
5500	1638	2220
5600	1665	2257
5700	1698	2301

PRESSURE IN: PSI	ft-lbs	NM
5800	1730	2346
5900	1758	2383
6000	1785	2420
6100	1818	2464
6200	1850	2508
6300	1878	2546
6400	1905	2583
6500	1935	2623
6600	1965	2664
6700	1995	2705
6800	2025	2745
6900	2055	2786
7000	2085	2827
7100	2115	2868
7200	2145	2908
7300	2175	2949
7400	2205	2990
7500	2233	3027
7600	2260	3064
7700	2293	3108
7800	2325	3152
7900	2353	3190
8000	2380	3227
8100	2410	3267
8200	2440	3308
8300	2473	3352
8400	2505	3396
8500	2533	3434
8600	2560	3471
8700	2590	3512
8800	2620	3552
8900	2650	3593
9000	2680	3634
9100	2710	3674
9200	2740	3715
9300	2770	3756
9400	2800	3796
9500	2830	3837
9600	2860	3878
9700	2890	3918
9800	2920	3959
9900	2950	4000
10000	2980	4040

Set the pressure on the pump that corresponds to the torque value.

Always ensure that gauge calibration certificate is current.