



Tool Model: LC 2 w/ Hex Link

Pressure/Torque Conversion Chart

| PRESSURE IN: PSI | ft-lbs | NM |
|------------------|--------|------|
| 1500 | 281 | 381 |
| 1600 | 300 | 407 |
| 1700 | 319 | 432 |
| 1800 | 337 | 457 |
| 1900 | 356 | 482 |
| 2000 | 374 | 507 |
| 2100 | 393 | 532 |
| 2200 | 411 | 557 |
| 2300 | 430 | 583 |
| 2400 | 449 | 609 |
| 2500 | 468 | 634 |
| 2600 | 486 | 659 |
| 2700 | 505 | 685 |
| 2800 | 524 | 710 |
| 2900 | 543 | 736 |
| 3000 | 561 | 761 |
| 3100 | 580 | 786 |
| 3200 | 598 | 811 |
| 3300 | 617 | 837 |
| 3400 | 636 | 862 |
| 3500 | 655 | 887 |
| 3600 | 673 | 912 |
| 3700 | 692 | 938 |
| 3800 | 711 | 964 |
| 3900 | 730 | 989 |
| 4000 | 748 | 1014 |
| 4100 | 767 | 1039 |
| 4200 | 785 | 1064 |
| 4300 | 804 | 1090 |
| 4400 | 823 | 1116 |
| 4500 | 842 | 1141 |
| 4600 | 860 | 1166 |
| 4700 | 879 | 1192 |
| 4800 | 898 | 1218 |
| 4900 | 917 | 1243 |
| 5000 | 935 | 1268 |
| 5100 | 954 | 1293 |
| 5200 | 972 | 1318 |
| 5300 | 991 | 1344 |
| 5400 | 1010 | 1369 |
| 5500 | 1029 | 1394 |
| 5600 | 1047 | 1420 |
| 5700 | 1066 | 1445 |

| PRESSURE IN: PSI | ft-lbs | NM |
|------------------|--------|------|
| 5800 | 1085 | 1471 |
| 5900 | 1104 | 1496 |
| 6000 | 1122 | 1521 |
| 6100 | 1141 | 1546 |
| 6200 | 1159 | 1571 |
| 6300 | 1178 | 1597 |
| 6400 | 1197 | 1623 |
| 6500 | 1216 | 1648 |
| 6600 | 1234 | 1673 |
| 6700 | 1253 | 1699 |
| 6800 | 1272 | 1725 |
| 6900 | 1291 | 1750 |
| 7000 | 1309 | 1775 |
| 7100 | 1328 | 1800 |
| 7200 | 1346 | 1825 |
| 7300 | 1365 | 1851 |
| 7400 | 1384 | 1876 |
| 7500 | 1403 | 1902 |
| 7600 | 1421 | 1927 |
| 7700 | 1440 | 1952 |
| 7800 | 1459 | 1978 |
| 7900 | 1478 | 2003 |
| 8000 | 1496 | 2028 |
| 8100 | 1515 | 2053 |
| 8200 | 1533 | 2078 |
| 8300 | 1552 | 2104 |
| 8400 | 1571 | 2130 |
| 8500 | 1590 | 2155 |
| 8600 | 1608 | 2180 |
| 8700 | 1627 | 2206 |
| 8800 | 1646 | 2232 |
| 8900 | 1665 | 2257 |
| 9000 | 1683 | 2282 |
| 9100 | 1702 | 2307 |
| 9200 | 1720 | 2332 |
| 9300 | 1739 | 2358 |
| 9400 | 1758 | 2383 |
| 9500 | 1777 | 2409 |
| 9600 | 1795 | 2434 |
| 9700 | 1814 | 2459 |
| 9800 | 1833 | 2485 |
| 9900 | 1852 | 2510 |
| 10000 | 1870 | 2535 |

Set the pressure on the pump that corresponds to the torque value.

Always ensure that gauge calibration certificate is current.