



Tool Model: Stealth-36 w/ Hex Link

Pressure/Torque Conversion Chart

| PRESSURE IN: PSI | ft-lbs | NM |
|------------------|--------|-------|
| 1500 | 4917 | 6666 |
| 1600 | 5255 | 7125 |
| 1700 | 5593 | 7583 |
| 1800 | 5931 | 8041 |
| 1900 | 6269 | 8500 |
| 2000 | 6607 | 8958 |
| 2100 | 6958 | 9434 |
| 2200 | 7309 | 9910 |
| 2300 | 7661 | 10386 |
| 2400 | 8012 | 10863 |
| 2500 | 8364 | 11339 |
| 2600 | 8715 | 11816 |
| 2700 | 9066 | 12292 |
| 2800 | 9417 | 12768 |
| 2900 | 9769 | 13244 |
| 3000 | 10120 | 13721 |
| 3100 | 10467 | 14191 |
| 3200 | 10814 | 14662 |
| 3300 | 11161 | 15132 |
| 3400 | 11508 | 15603 |
| 3500 | 11855 | 16073 |
| 3600 | 12202 | 16543 |
| 3700 | 12549 | 17014 |
| 3800 | 12896 | 17484 |
| 3900 | 13243 | 17955 |
| 4000 | 13590 | 18425 |
| 4100 | 13943 | 18903 |
| 4200 | 14295 | 19381 |
| 4300 | 14647 | 19858 |
| 4400 | 14999 | 20336 |
| 4500 | 15352 | 20814 |
| 4600 | 15704 | 21291 |
| 4700 | 16057 | 21769 |
| 4800 | 16409 | 22247 |
| 4900 | 16761 | 22725 |
| 5000 | 17113 | 23202 |
| 5100 | 17466 | 23680 |
| 5200 | 17819 | 24159 |
| 5300 | 18172 | 24638 |
| 5400 | 18525 | 25116 |
| 5500 | 18878 | 25594 |
| 5600 | 19230 | 26072 |
| 5700 | 19583 | 26551 |

| PRESSURE IN: PSI | ft-lbs | NM |
|------------------|--------|-------|
| 5800 | 19936 | 27029 |
| 5900 | 20289 | 27508 |
| 6000 | 20642 | 27986 |
| 6100 | 20998 | 28469 |
| 6200 | 21354 | 28952 |
| 6300 | 21710 | 29434 |
| 6400 | 22066 | 29917 |
| 6500 | 22422 | 30400 |
| 6600 | 22778 | 30882 |
| 6700 | 23134 | 31365 |
| 6800 | 23490 | 31848 |
| 6900 | 23846 | 32330 |
| 7000 | 24202 | 32813 |
| 7100 | 24558 | 33296 |
| 7200 | 24914 | 33778 |
| 7300 | 25271 | 34262 |
| 7400 | 25627 | 34745 |
| 7500 | 25984 | 35228 |
| 7600 | 26340 | 35712 |
| 7700 | 26696 | 36194 |
| 7800 | 27052 | 36677 |
| 7900 | 27409 | 37160 |
| 8000 | 27765 | 37644 |
| 8100 | 28114 | 38116 |
| 8200 | 28462 | 38589 |
| 8300 | 28811 | 39061 |
| 8400 | 29159 | 39534 |
| 8500 | 29373 | 39823 |
| 8600 | 29586 | 40113 |
| 8700 | 30070 | 40768 |
| 8800 | 30553 | 41424 |
| 8900 | 30902 | 41896 |
| 9000 | 31250 | 42369 |
| 9100 | 31597 | 42839 |
| 9200 | 31944 | 43310 |
| 9300 | 32292 | 43781 |
| 9400 | 32639 | 44252 |
| 9500 | 32986 | 44722 |
| 9600 | 33333 | 45193 |
| 9700 | 33681 | 45664 |
| 9800 | 34028 | 46135 |
| 9900 | 34375 | 46606 |
| 10000 | 34722 | 47076 |

Set the pressure on the pump that corresponds to the torque value.

Always ensure that gauge calibration certificate is current.